

be capable of reaching a height of one-third the beam of the vessel.

(b) The capacity of branch vents or vent headers shall depend upon the number of cargo tanks connected to such branch or header as provided for in the Table 38.20-1(b), and upon the total safety relief valve discharge capacity.

TABLE 38.20-1(b)—CAPACITY OF BRANCH VENTS OR VENT HEADERS

Number of cargo tanks	Percent of total valve discharge
1 or 2 .....	100
3 .....	90
4 .....	80
5 .....	70
6 or more .....	60

(c) In addition to the requirements specified in paragraphs (a) and (b) of this section, the size of the branch vents or vent headers, shall be such that the back pressure in the relief valve discharge lines shall not be more than 10 percent of the safety relief valve setting. In nonpressure vessel vent systems, however, where the maximum back pressure of 10 percent of the relief valve setting is insufficient to move the gases through any but an extremely large diameter vent pipe, the back pressure may exceed 10 percent provided:

(1) The pressure in the tank during venting does not exceed 120 percent of the tank maximum allowable pressure; and,

(2) The safety relief valve is sized to discharge the required capacity with the tank pressure and vent back pressure actually used.

(d) Return bends and restrictive pipe fittings are not permitted.

(e) Vents and headers shall be so installed as to prevent excessive stresses on safety relief valve mountings.

(f) The vent discharge riser shall be so located as to provide protection against mechanical injury and such discharge pipes shall be fitted with loose raincaps or other suitable means to prevent entrance of rain or snow.

(g) No valve of any type shall be fitted in the vent pipe between the safety relief valve and the vent outlets.

(h) Provisions shall be made to drain condensate from the vent header piping. Special precautions shall insure that condensate does not accumulate at or near the relief valves.

(i) Relief valves discharging liquid cargo shall not be connected to the branch vent or vent header lines from the cargo tanks. They may, however, be connected to an accumulator, the vapor space of which, may in turn, be connected to the vent header system. Relief valves in the cargo piping system may discharge back to the cargo tanks.

(j) Vapor discharged to the atmosphere in accordance with §38.05-25(b) shall utilize valves separate from the safety relief valves.

#### §38.20-5 Venting—T/ALL.

(a) Safety relief valves on cargo tanks in barges may be connected to individual or common risers which shall extend to a reasonable height above the deck. An alternate arrangement consisting of a branch vent header system as required by §38.20-1 may be installed. In any case, the provisions of §38.20-1 (d) through (j) shall apply.

(b) Arrangements providing for venting cargo tanks at sea on unmanned barges will be considered by the Commandant upon presentation of plans.

#### §38.20-10 Ventilation—T/ALL.

(a) A power ventilation system shall be provided for compartments containing pumps, compressors, pipes, control spaces, etc. connected with the cargo handling facilities. These compartments shall be ventilated in such a way as to remove vapors from points near the floor level or bilges, or other areas where vapor concentrations may be expected. The compartments shall be equipped with power ventilation of the exhaust type having capacity sufficient to effect a complete change of air in not more than 3 minutes equal to the volume of the compartment and associated trunks.

(b) The power ventilation units shall not produce a source of vapor ignition in either the compartment or the ventilation system associated with the compartment. Inlets to exhaust ducts shall be provided and located at points where concentrations of vapors may be